

**TOOLS REQUIRED FOR ASSEMBLY:**

Cordless Drill W/ #2 Phillips Bit Driver  
.250 Short Arm Hex Key

**301CPU HOLDER INSTALLATION INSTRUCTIONS**

Parts List		
ITEM	QTY	DESCRIPTION
A	1	301CPU Holder
B	4	10x3/4" Screw
C	1	Support Bracket
D	1	.250 Short Arm Hex Key

- 1) Measure CPU depth, height and width.
- 2) Adjust (A) 301CPU holder to approximate dimensions without CPU (Dim 1 & Dim 2)  
**(Note: Make sure worksurface is at least 1" thick!)**
- 3) Mount (A) 301CPU holder with (C) Bracket and (4) (B) 3/4" screws as shown.  
**(Note: Be sure to consider CPU depth when mounting.)**
- 4) Slide CPU into place and adjust bottom support to fit CPU width.
- 5) Tighten Hex key bolt until CPU is secured and proper height.

